


Actual Size: 100% when viewed on A4 paper




Actual Size: 100% when viewed on A4 paper

POSITION A




Screen Print

POSITION B




POSITION D




Pad Print

POSITION E




POSITION D



Direct Digital

POSITION E



Please note when pen is printed in position D, print is not visible when in the notebook holder.